## TIMBER TREATMENT CLASSES AND USES

HAZARD CLASS	TYPICAL PRESERVATIVE	EXPOSURE	TYPICAL USES
H1.2	BORON WATER BORNE AZOLE	GENERALLY FOR STRUCTURAL USE INSIDE	WALL FRAMING, FLOOR AND CEILING FRAMING, ROOF TRUSSES
H3.1	BORON WATER BORNE AZOLE LOSP AZOLE TBT	GENERALLY NON-STRUCTURAL USE OUTSIDE ABOVE GROUND EXPOSED TO WEATHER IF PAINTED	EXTERIOR JOINERY AND CLADDING, (MUST BE PAINTED AND USED IN A VERTICAL PLANE), CAVITY BATTENS
H3.2	CCA (COPPER, CHROME, ARSENIC)  COPPER QUAT*  COPPER AZOLE*  COPPER NAPHTHENATE	CAN BE STRUCTURAL OR NON-STRUCTURAL OUTSIDE EXPOSED TO WEATHER ABOVE GROUND	CLADDING, DECKING, PALINGS, HAND RAILS, STRUCTURAL TIMBER SUCH AS JOISTS AND BEARERS FOR DECKS AND WALKWAYS
H4	CCA COPPER QUAT* COPPER AZOLE*	NON-STRUCTURAL USE OUTSIDE IN GROUND CONTACT OR IN FRESH WATER OR, STRUCTURAL USE ABOVE GROUND AND EXPOSED TO WEATHER	POSTS, PERGOLAS, FENCES, AND GARDEN EDGING
H5	CCA COPPER QUAT* COPPER AZOLE*	STRUCTURAL USE OUTSIDE IN GROUND CONTACT EXPOSED TO WEATHER OR IN FRESH WATER	HOUSE PILES AND POLES RETAINING WALLS FRESH WATER MARINAS
H6	CCA	STRUCTURAL USE IN SEA WATER OR ESTUARINE GROUND	SALT WATER WHARF PILINGS AND MARINAS

\*INCLUDES ALKALINE AND MICRONISED SYSTEMS

DO NOT BURN TREATED TIMBER OR USE IN DIRECT CONTACT WITH FOOD. WASH HANDS AFTER HANDLING TREATED TIMBER.

